


COMPREHENSIVE INSTRUCTION MANUAL



AUTOMOTIVE MULTIMETER

Complete "step-by-step" electrical systems
troubleshooting guide included.



DISCLAIMER:

This manual tells you how to use the meter to perform diagnostic tests and to find possible locations of vehicle problems. It does **NOT** tell you how to correct the problems.







All information, illustrations, and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

SAFETY:

The instrument complies with class II, overvoltage CAT.III of the IEC1010-1(EN61010-1) standard. If the equipment is used in a manner not specified, the protection provided by the equipment may be impaired.

  When servicing, use only specified replacement parts or equivalent.

The symbols used on this instrument are:

-  Caution, risk of electric shock
-  Caution, refer to accompanying documents
-  Equipment protected throughout by Double insulation (Class II)
-  Alternating current
-  Direct current
-  Ground



This product complies with the requirements of the following European Community Directives: 89/336/EEC (Electromagnetic Compatibility) and 73/23/EEC (Low Voltage) as amended by 93/68/EEC (CE Marking).

However, electrical noise or intense electromagnetic fields in the vicinity of the equipment may disturb the measurement circuit. Measuring instruments will also respond to unwanted signals that may be present within the measurement circuit. Users should exercise care and take appropriate precautions to avoid misleading results when making measurements in the presence of electromagnetic interference.

Introduction

About This Manual

Chapter	Description
Introduction	• Table of Contents
	• Safety Warnings
Getting Started	• Meter Basics
	• Meter Functions
	• Maintenance
Basic Diagnostic Testing	• Battery Testing
	• Voltage Drop Testing
	• Starter Motor Testing
	• Charging System Testing
	• Ignition System Testing
Basic Component Testing	• Computer Controlled Systems
	• Component Tests (Input)
	• Component Tests (Output)
Specifications	• General Specifications
	• Electrical Specifications


Contents

Introduction	1
Safety	2
Getting Started	5
Meter Basics	6
Digital and Analog display	7
Function and Range Select	8
Push-button Functions	9
Alternate Function	9
Range Select	9
Data Hold (Hold)	9
Meter Functions	10
Voltage	10
Resistance	11
Audible Continuity	12
Diode Check	13
Temperature	14
Frequency	15
RPM / x 10RPM	16
Duty Cycle	17
Dwell	18
AC or DC Current	19
Maintenance	20
Fuse and Battery Replacement	20
Trouble Shooting	21
Basic Diagnostic Testing	22
Electrical System Diagnostics	23
Battery Testing	24
[1] Battery Test (Surface Discharge)	24
[2] Static Battery Test (No Load)	25
[3] Battery Test (Parasitic Load)	26
[4] Battery Test (Load)	27
Voltage Drop Testing	28
[1] Negative (-) Engine Ground	29
[2] Negative (-) Chassis Ground	30
[3] Battery Power to Starter Solenoid (+)	31
[4] Battery Power to Complete Starter Circuit (+)	32
Starter Motor Testing	33
[1] Starter - Current	33

Contents Cont'd...

Basic Diagnostic Testing Cont'd	34
Charging System Tests	34
[1] Battery (+)	34
[2] Alternator Voltage Output (+), Loaded	35
[3] Alternator Amperage (A) Output, Battery	36
Ignition System Tests	37
[1] Ignition Coil, Primary Resistance Test (Ω)	37
[2] Ignition Coil, Secondary Resistance Test (Ω)	38
[3] Secondary Ignition Wire Resistance Test (Ω)	39
[4] Distributor Cap/Rotor Resistance Test (Ω)	40
[5] Pick-up Coil Resistance/Voltage Test (Ω)	41
[6] Hall Effect Sensor Voltage Test (V)	42
Basic Component Testing	43
Computer Controlled Systems	44
Basic Diagnostics for the Computer Controlled Engine	45
Self-Diagnostic Computer Systems	46
Component Testing	47
Duty Cycle, What is it?	48
Frequency (Hz), What is it?	48
Component Tests (Input)	49
[1] Temperature Tests	49
[2] Thermistor (Variable Resistance, 2-wire)	50
[3] Potentiometers (Variable Resistance, 3-wire)	53
[4] Oxygen Sensor (O ₂) Test	56
[5] Pressure Sensor Tests	57
Component Tests (Output)	58
Output Devices	58
Specifications	59
General Specifications	59
Electrical Specifications	60

This chapter covers brief introductory information and safety precautions.



Safety

⚠ DANGER

- Engines produce carbon monoxide which is odorless, causes slower reaction time, and can lead to serious injury. When the engine is operating, keep service areas **WELL VENTILATED** or attach the vehicle exhaust system to the shop exhaust removal system.



- Set the parking brake and block the wheels before testing or repairing the vehicle. It is especially important to block the wheels on front-wheel drive vehicles: The parking brake does not hold the drive wheels.



- Wear an eye shield when testing or repairing vehicles.



Exceeding the limits of this meter is dangerous. It will expose you to serious or possibly fatal injury. Carefully read and understand the cautions and the specification limits of this meter.

- Voltage between any terminal and ground must not exceed 600V DC or AC.



- Use caution when measuring voltage above 25VAC or DC.

- Circuit tested must be protected by a 10A fuse or circuit breaker.

- Do not use the meter if it has been damaged.

- Do not use the test leads if the insulation is damaged or if metal is exposed.

- Use current clamps to measure circuits exceeding 10A.

Introduction

Safety Cont'd...

⚠ Danger

- Avoid electrical shock: Do not touch the test leads, tips or the circuit being tested.
- Do not try a voltage measurement with the test leads in the 10A or the mA terminal.
- When testing for the presence of voltage or current, make sure the meter is functioning correctly. Take a reading of a known voltage or current before accepting a zero reading.
- Choose the proper range and function for the measurement. Do not try voltage or current measurements that may exceed the ratings marked on the Function/Range switch or terminal.
- When measuring current, connect the meter in series with the load.
- Never connect more than one set of test leads to the meter.
- Disconnect the live test lead before disconnecting the common test lead.
- The mA and the 10A terminals are protected by fuses. To avoid possible injury or damage, use only in circuits limited to 320mA or 10A for 60 seconds.




See also...

- Fuse Replacement

Introduction

Safety Cont'd...

IMPORTANT

- To maintain accuracy of the meter, replace the discharged battery immediately when the battery symbol  appears on the meter display.
- Avoid measuring error from outside interference: keep the meter away from spark plug or coil wires.
- Avoid damaging the meter when testing voltage: Disconnect the test leads from the test points before changing functions.
- Do not exceed the limits shown in the table below:


Function	Terminal	Input limit
AC Volts	V/ Ω /RPM	600VAC rms
DC Volts		600VDC
Frequency	V/ Ω /RPM	500V AC/DC
[1] Ohm(resistance)		
Diode		
AC/DC μ A, mA	μ A/mA	320mA AC/DC
AC/DC 10A	10A	*10A AC/DC
RPM	V/ Ω /RPM	500V AC/DC
Duty Cycle (%)		
Dwell angle		

* 10Amp measurement for 60 seconds maximum.

[1] Ohms can not be measured if voltage is present, ohms can be measured only in a non-powered circuit. However, the meter is protected to 500 volts.

Getting Started

This chapter will help you get started. It describes the basic functions of the Meter.



Getting Started

Meter Basics

1. Digital and Analog display

Display features:

- Four character digital display
- Symbols to identify function
- Analog bar graph

The digital display is best for stable input. The bar graph is best for rapidly changing input.

2. Function buttons

Press the button to select a function. A symbol will display to verify your choice.

3. Rotary Selector Switch


Turn this switch to select a function or turn the meter OFF.

4. Temperature Terminal

Insert the temperature probe in this terminal.

5. Test Lead Terminals


The Black test lead is used in the Common (COM) terminal for all tests. The Red test lead is used to measure Amps or Volts.



Getting Started

Meter Basics Cont'd...

Digital and Analog display



Getting Started

Meter Basics Cont'd...


Function and Range Select

Turn the rotary switch in either direction to select a function.

The Range is automatically selected by the meter. But, you can also select a range within a function by pressing the range button.

Always select a range higher than you expect the current or voltage to be. Then select a lower range if better accuracy is needed.

- If the range is too high, the readings are less accurate.
- If the range is too low, the meter shows OL (over limit).




Getting Started

Push-button Functions


Alternate Function Button

Press the Alternate Function button to toggle between DC and AC in the voltage and current measurements. Press the button to toggle to the resistance, audible and diode modes, if the rotary switch is set to Ω position.



Range Select

The range is automatically selected by the meter. But, you can also manually select a range within a function by pressing the RANGE button.



Range Exit

To exit the RANGE mode and return to autoranging, press and hold the RANGE button for 2 seconds.


Note:

- If the range is too high, the readings are less accurate.
- If the range is too low, the meter shows OL (over limit).

Data Hold

The Data Hold Feature stores the last reading in memory.

- Press the Data Hold button once to hold the present reading.
- Press the Data Hold button again to exit and resume readings.



Getting Started

Meter Functions - Voltage (V)

- ⇒ The meter will automatically select the best voltage (V) range.
- ⇒ Press the Alternate Function button to select AC or DC.

Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.

Touch the Black probe to ground or to the negative (-) circuit.

Touch the Red probe to the circuit coming from the power source.


IMPORTANT: voltage must be measured in parallel (Red probe measuring circuit from power source).

⇒ Accuracy

Selection of a lower range will move the decimal point one place and increase the accuracy of the reading. An OL (Over Limit) display means the range is too low, select the next higher range.

⇒ Analog Bar Graph

The Bar graph is easier to read when the data causes the digital display to rapidly change. It is also useful for trend setting or directional data.



⚠ WARNING

When measuring voltage, be sure the Red test lead is in the terminal marked "V". If the test lead is in an Amp (A) or Milliampere (mA) terminal, you may be injured or the meter damaged.

Getting Started

Meter Functions - Resistance (Ω)


IMPORTANT: If you are testing an application that has capacitors in the circuit, be sure to turn the power OFF on the test circuit and discharge all capacitors. Accurate measurement is not possible if external or residual voltage is present.

⇒ Select the resistance (Ω) setting with the rotary switch.

⇒ Select the resistance (Ω) range with the button labeled "RANGE" if a more accurate measurement is desired.

Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.
- Touch the test lead probes across the resistor to be tested.



Getting Started

Meter Functions - Audible Continuity (🔊)

IMPORTANT: Turn the power OFF on the test circuit

⇒ Select the Audible Continuity (🔊) range with the rotary switch.


⇒ Press the Alternate Function button to select Audible Continuity.

Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.

Connect one test probe to each end of the circuit to be tested.

- Circuit complete, the meter will "beep".
- Circuit open, there is no "beep" and the display shows OL (over limit).



Getting Started

Meter Functions - Diode Check \rightarrow

IMPORTANT: Turn the power OFF to the test circuit

- \Rightarrow Select the Diode Check (\rightarrow) setting with the rotary switch.
- \Rightarrow Press the Alternate Function button to select Diode check.

Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.

Touch the Black test probe to the negative (-) side of the diode.


Touch the Red test probe to the positive (+) side of the diode.

Reverse the probes: Black to the positive (+) side and Red to the negative (-) side.

Note:

A "good" diode will read low in one direction and high in the other direction when the probes are reversed. A "defective" diode will have the same reading in both directions or read between 1.0 to 3.0 V or OL (over limited) in both directions.

Diode	Reverse Probes	
	- to +	+ to-
Good	0.4 to 0.9V	OL
	OL	0.4 to 0.9V
Bad	OL	1.0 to 3.0V
	1.0 to 3.0V	OL
	0.4 to 0.9V	0.4 to 0.9V
	OL	OL
	.000V	.000V



Getting Started


Meter Functions - Temperature ($^{\circ}$ C/ $^{\circ}$ F)

IMPORTANT: To avoid heat damage to the meter, keep it away from sources of very high temperature. The life of the temperature probe is also reduced when subjected to very high temperatures (operating range is -4° to $1,400^{\circ}$ F)

\Rightarrow Select desired temperature unit of measurement ($^{\circ}$ C/ $^{\circ}$ F) with the rotary switch.

\Rightarrow Insert the temperature probe connector into the K-type thermocouple socket.

Touch the end of the temperature sensor to the area or surface of the object to be measured.



Getting Started

Meter Functions - Frequency (Hz)


⇒ Set the rotary switch to the Frequency range that gives the most accurate measurement reading.

Insert:

- Black lead in COM terminal.
- Red lead in V/Ω/RPM terminal.

Connect the Black test probe to ground.

Connect the Red test probe to the "signal out" wire of the sensor to be tested.



Getting Started

Meter Functions - RPM/X10RPM

⇒ Select the RPM range with the rotary switch.

OR

⇒ Select the X10RPM range with rotary switch (1,000 to 12,000 RPM). *Multiply the displayed reading times ten to get actual RPM.*



Insert the inductive pick-up connecting terminal into the meter.

- Ground lead in COM terminal.
- Output lead in V/Ω/RPM terminal.

Connect the inductive pickup to a spark plug wire. If no reading is received, unhook the clamp, turn it over and connect again.

Note:

- Position the inductive pick-up as far away from the distributor and the exhaust manifold as possible.
- Position the inductive pick-up to within six inches of the spark plug or move it to another plug wire if no reading or an erratic reading is received.



Getting Started

Meter Functions - Duty Cycle (%)

⇒ Select the % Duty Cycle range with the rotary switch.


Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.

Connect the Black test probe to the ground.

Connect the Red test probe to the signal wire circuit.

The illustration for a mixture control solenoid is shown with the metering rod in the closed position.



Getting Started

Meter Functions - Dwell


⇒ Select desired Dwell range with the rotary switch.

Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.

Connect the Black test probe to ground.

Connect the Red test probe to the wire that connects to the breaker points (see illustration).



Getting Started

Meter Functions - AC or DC Current (A)

IMPORTANT: All current measured flows through the meter. It is important that you *do not*:

- Measure current greater than 600 Volts AC or DC, with respect to ground.
- Exceed 60 seconds when measuring continuous current between 1A - 10A. Allow five minutes for cool-down before continuing.

⇒ Select the 10A, mA or μ A range with the rotary switch.

⇒ Press the Alternate Function button to select AC or DC.

Insert:


- Black lead in COM terminal.
- Red lead in the 10A or mA terminal (select 10A if you are unsure of the current draw).

IMPORTANT:

Turn OFF all power to the circuit or disconnect the circuit from the power source.

Connect:

- The Red probe to the side of the circuit closest to the power source.
- The Black probe to the side of the circuit to ground.
- Turn the power ON and test.



Note:

Current must always be measured with the meter test probes connected in series, as described.

Getting Started

Maintenance

Fuse and Battery Replacement

⚠ WARNING:

- Avoid electrical shock; remove test leads before opening case.
- Do not operate the meter or rotate the meter switch when the case is open.

1. To replace a battery or fuse, loosen the three screws in the case back and lift off the front case.

- Replace the battery with an 9 Volt battery (NEDA 1604, IEC 6F 22).

2. If no current measurements are possible, check for a blown overload protection fuse.

Important:

- To prevent contamination of the circuits, your hands must be clean and the printed circuit board must be held by the edges.
- Replace the fuses with the same type of fuse.
 - 10A is a F10A, 600V high energy, fast acting fuse.
 - mA is a F500mA, 250V fast acting fuse.
- Make sure the replacement fuse is centered in the fuse holder.

3. Re-assemble the case, then fasten the three screws.

Getting Started

Trouble Shooting

1. Meter will not turn ON.

- Check the battery contacts for a tight fit.
- Check for a minimum battery voltage of 8.0 volts.

2. Ampere reading is erratic or there is no reading at all.

- Disassemble the meter back cover and test the fuses for continuity.

3. Meter reading is erratic.


- Printed circuit board contaminated from handling with hands.
- Low battery.
- Open circuit in a test lead (frayed or broken wire).
- Wrong range selected.
- "Blown" fuse.

4. Meter readings do not change.

- "Hold" feature is still toggled ON.

Basic Diagnostic Testing


This chapter leads you through a systematic series of tests that check the vehicle electrical system. These tests should be performed before testing individual components.



Basic Diagnostic Testing

Electrical System Diagnostics

It is important to diagnose a vehicle electrical problem thoroughly and efficiently.



The series of tests that follow check primary areas that are responsible for the majority of the electrical problems found in an automobile. Perform these basic tests first, even if a vehicle has a trouble code set in the computer. A component malfunction detected by the computer can be caused by a basic ground problem in the electrical system. Simply replacing a failed component will not fix the problem if a poor ground caused the component failure.

The tests begin by checking the main source of power and the chassis ground circuit connections. Ground circuits are one of the least understood but potentially most troublesome areas of automotive electronics. An excessive voltage drop in a ground circuit effects the entire electrical circuit. This is why it is important to make sure the basic circuits are in good shape before checking trouble codes and components.

Basic Diagnostic Testing

Battery Testing

[1] Battery Test (Surface Discharge)

Note:


- Remove the positive and negative battery cables and thoroughly clean the cable terminals and the battery posts. Reassemble and begin testing.
- The ignition switch must be OFF to prevent damaging the vehicle computer when connecting or disconnecting battery cables.

This test checks for a low current discharge across the battery case.

- Set the rotary switch to Voltage.
- Connect the negative (-) lead to the negative battery post.
- Touch the positive (+) lead to the battery case around the positive (+) battery post: Do not touch the post.

A reading of more than 0.5V indicates excessive surface discharge.

Dirt, moisture and corrosion are a cause of surface discharge. Clean the battery with a baking soda and water solution. Do not allow the solution to get into the battery.



Basic Diagnostic Testing

Battery Testing Cont'd...

[2] Static Battery Test (No Load)

This test checks for battery charge state.

- Turn the headlights on for 15 seconds to dissipate battery surface charge.

IMPORTANT: The ignition switch must be OFF when connecting or disconnecting battery cables to prevent damaging the vehicle computer.


- Disconnect the negative (-) battery terminal.
- Set the rotary switch to Voltage.
- Connect the positive (+) lead to the positive (+) battery post.
- Connect the negative (-) lead to the negative (-) battery post.

A reading of less than 12.4V indicates an undercharged battery. Recharge before testing.

NO LOAD TEST

Meter Reading	Battery Charge
12.6V	100%
12.4V	75%
12.2V	50%
12.0V	25%

Note:
Leave the battery cable unhooked and proceed to the test on the following page.



Basic Diagnostic Testing

Battery Testing Cont'd...

[3] Battery Test (Parasitic Load)


This tests for excessive parasitic drain on the battery.

- Turn the ignition switch and all accessories OFF.
Important: Do not start the vehicle during this test; meter damage may result.
- Set the rotary switch to 10A.
- Insert the positive (+) lead into the 10A meter terminal.
- Disconnect the battery positive (+) cable.
- Connect the positive (+) lead to the positive (+) battery terminal.
- Connect the negative (-) lead to the disconnected positive (+) battery terminal.

Parasitic draw should not exceed 100mA.

If there is excessive draw, remove the circuit fuses, one at a time, until the excessive draw is located. Also check the non-fused applications such as head lights, computer relays and capacitors in the instrument panel.

Reconnect the battery cable for the next test.



Basic Diagnostic Testing

Battery Testing Cont'd...

[4] Battery Test (Load)

This tests the battery's capacity to deliver sufficient cranking voltage.

- Set the rotary switch to Voltage.
- Connect the positive (+) lead to the positive (+) battery terminal.
- Connect the negative (-) lead to the negative (-) battery terminal.
- Disable the ignition; crank the engine for 15 seconds.


Check the display. A reading of less than 9.60V@ 70°F indicates a weak battery. Recharge/replace before testing.

VOLTAGE LOAD TEST

Meter Reading	Battery/air Temperature
10.0V	90°F/33°C
9.8V	80°F/27°C
9.6V	70°F/21°C
9.4V	60°F/16°C
9.2V	50°F/10°C
9.0V	40°F/4°C
8.8V	30°F/-1°C
8.6V	20°F/-7°C

Note:

- For each 10° above or below 70°, add or subtract 0.1 volt.
- Battery temperature can be checked with the meter temperature probe.




Basic Diagnostic Testing

Voltage Drop Testing

Resistance, What is it?

Resistance is an opposing force, created by a circuit or component, to the flow of electrical current.

There is a small amount of natural resistance when voltage flows through wires, switches, grounds or connections. The resistance increases beyond acceptable limits if corrosion develops, fittings become loose or wires fray. Resistance increases each time something, such as wire, a switch, connections, or the ground are added in the circuit.



Voltage Drop, What is it?

Voltage drop is the difference in voltage potential when measured across a circuit or component creating resistance.


The resistance decreases the amount of voltage available. The bulb will not light or the motor will not turn if the voltage is too low.

Maximum Voltage Drop

Maximum voltage drop should not be more than 0.1 volt per wire, ground, connection, switch or solenoid.

What Should be Tested?

Each wire, ground, connection, switch, solenoid and the complete circuit should be tested. Each connection point is a potential source of increased resistance.



Total resistance should be no more than 0.4V Max. for the example shown.

Basic Diagnostic Testing

Voltage Drop Testing


[1] Negative (-) Engine Ground

This test checks for engine ground efficiency.

- Set the rotary switch to Voltage.
- Touch the positive (+) lead to the positive (+) battery post and the negative (-) lead to the negative (-) battery post. Note the reading...this will be the base voltage to compare your test voltage reading against.
- Connect the positive (+) lead to a clean spot on the engine block.
- Connect the negative (-) lead to the negative battery post.
- Disable the ignition so the engine doesn't start; crank the engine for 2-3 seconds.

The example shown has 2 connectors, 1 wire, 1 ground and 1 terminal to battery post. A voltage drop of more than 0.5 volts would indicate a poor ground circuit.

Clean and inspect the battery cable connections and the ground; test again.



Important: Repeat this test when the engine is thoroughly warmed up. Heat expansion of metal may cause resistance to increase.

Basic Diagnostic Testing

Voltage Drop Testing Cont'd...


[2] Negative (-) Chassis Ground

This test checks for chassis ground efficiency.

- Set the rotary switch to Voltage.
- Establish the base voltage that you will compare test voltage against (see base voltage, Volt Drop Test [1]).
- Connect the positive (+) lead to the point on the fender, fire wall or vehicle frame where the accessory ground is fastened.
- Connect the (-) lead to the negative (-) battery terminal.
- Turn all of the accessories ON (bright lights, A/C fan - high, rear window defroster, windshield wipers, etc.).
- Disable the ignition so the engine doesn't start; crank the engine for 2-3 seconds.

The example shown has 2 connectors, 1 wire, 1 ground and 1 terminal to battery post. A voltage drop of more than 0.5 volts would indicate a poor ground circuit.

Clean and inspect the battery cable connections and the ground; test again.



Important: Repeat this test when the engine is thoroughly warmed up. Heat expansion of metal may cause resistance to increase.


Basic Diagnostic Testing

Voltage Drop Testing Cont'd...

[3] Battery Power to Starter Solenoid (+)

This test checks battery source efficiency to the starter solenoid.

- Set the rotary switch to Voltage.
- Establish the base voltage that you will compare test voltage against (see base voltage, Volt Drop Test [1])
- Connect the positive (+) lead to the positive (+) battery terminal.
- Connect the negative (-) lead to the positive (+) terminal on the starter solenoid.
- Disable the ignition so the engine doesn't start; crank the engine for 2-3 seconds.



The example shown has 2 connectors and 1 wire. A voltage drop of more than 0.3 volts would indicate a poor circuit.

Clean and inspect the battery cables and cable connections; test again.

Important: Repeat this test when the engine is thoroughly warmed up. Heat expansion of metal causes resistance to increase.

Basic Diagnostic Testing

Voltage Drop Testing Cont'd...

[4] Battery Power to Complete Starter Circuit (+)

This test checks battery power efficiency to the starter through the starter solenoid.


- Set the rotary switch to voltage.
- Establish the base voltage that you will compare test voltage against (see base voltage, Volt Drop Test [1]).
- Connect the positive (+) lead to the (+) battery terminal.
- Connect the negative (-) lead to the positive (+) terminal on the starter motor.
- Disable the ignition so the engine doesn't start; crank the engine for 2-3 seconds.

The example shown has 4 connectors, 2 wires and 2 solenoid connections. A voltage drop of more than 0.8 volts would indicate a poor circuit.

Clean and inspect the battery and starter cables, solenoid and cable connections; test again.

Note:

A defective starter solenoid may cause an excessive voltage drop; check the cables and connections before replacing the solenoid.



Important: Repeat this test when the engine is thoroughly warmed up. Heat expansion of metal causes resistance to increase.


Basic Diagnostic Testing

Starter Motor Testing

[1] Starter - Current

The Battery tests and the Voltage Drop tests have verified that there is adequate battery voltage at the starter. Next, check for excessive starter motor current draw.

- Connect a Current Clamp around the negative (-) or positive (+) battery cable.
- Set the rotary switch to the Voltage setting.
Note: 1mV = 1Amp.
- Disable the ignition so the engine doesn't start; crank the engine for 2-3 seconds.




Black (-) Red (+)

Note:

The current clamp measures amps in the direction of electrical flow. Make sure the arrow on the clamp is pointed in the direction of the current flow in the cable.

Quick Test,

Turn the ignition and all accessories OFF. Place the clamp on the battery cable, then turn the headlights on. If the reading is not negative, disconnect the clamp, turn it over and reconnect.



Approximate Amperage Draw

4 Cyl.	150-180 Amp. Maximum
6-8 Cyl., under 300 CID	180-210 Amp. Maximum
6-8 Cyl., over 300 CID	250 Amp. Maximum

Basic Diagnostic Testing

Charging System Tests


[1] Battery (+)

This test checks for alternator output voltage at the battery.


- Set the rotary switch to Voltage.
- Connect the positive (+) lead to the positive (+) battery terminal.
- Connect the negative (-) lead to the negative (-) battery terminal.
- Make sure all vehicle accessories are turned OFF.
- Start the engine and hold at 1500 RPM.

A reading of 13.1-15.5 volts is an acceptable charging rate. If the voltage is low check for:

- Loose, cracked, or glazed drive belt
- Loose or faulty wires or connectors
- Defective alternator or regulator. See [2] Alternator Voltage Output (+), Loaded.



Black (-) Red (+)



Basic Diagnostic Testing


Charging System Tests Cont'd...

[2] Alternator Voltage Output (+), Loaded

This test checks for alternator output voltage. This test is necessary only if the vehicle failed [1] Battery (+) test.

- Set the rotary switch to the Voltage setting.
- Connect the positive (+) lead to the battery (B+) output post on the back of the alternator.
- Connect the negative (-) lead to the negative (-) battery terminal.
- Start the engine and hold a 1500 RPM.

A reading of 13.1-15.5 volts is an acceptable charging rate.



Basic Diagnostic Testing

Charging System Tests Cont'd...

[3] Alternator Amperage (A) Output, Battery

This test checks for alternator charging rate efficiency at the battery.

- Connect Current Clamp leads to the meter.
- Connect the Current Clamp around the negative (-) or positive (+) battery cable.
- Set the rotary switch to the Voltage setting.
Note: 1mV = 1 Amp.
- Make sure all vehicle accessories are turned OFF.
- Start the engine and hold at 1500 RPM.


The amperage reading should be 5 amps or better.

Note:

The current clamp measures amps in the direction of electrical flow. Make sure the arrow on the clamp is pointed in the direction of the current flow in the cable.

Quick Test,

Place the clamp on the battery cable, then turn the headlights on. If the reading is not negative, disconnect the clamp, turn it over and reconnect.



Basic Diagnostic Testing

Ignition System Tests

[1] Ignition Coil, Primary Resistance Test (Ω)

This test checks primary winding resistance.

Important: Test the ignition coil cold and hot.

- Set the rotary switch to the Resistance (Ω) setting.



Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.
- Disconnect the coil from the vehicle wiring harness.

• Note: The resistance in the meter leads must be subtracted to get an accurate measurement at the 1.0-2.0 range.

- Connect the negative (-) lead to the negative (-) terminal on the coil.
- Connect the positive (+) lead to the positive (B+) terminal on the coil.

Typical measurements are between 1.0-2.0 Ω 's. Consult the manufacturer's specifications for required resistance measurements.



GM DIS Coil, Type II - Both primaries located on back of coil.

Basic Diagnostic Testing

Ignition System Tests Cont'd...

[2] Ignition Coil, Secondary Resistance Test (Ω)

This test checks secondary winding resistance.

Important: Test the ignition coil cold and hot.



Set the rotary switch to the Resistance (Ω) setting.

Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.
- Disconnect the coil from the vehicle wiring harness.

- Connect the negative (-) lead to the high tension terminal on the coil.
- Connect the positive (+) lead to the positive (B+) terminal on the coil.

Typical measurements are between 6,000-30,000 Ω 's. Consult the manufacturer's specifications for required resistance measurements.



GM DIS Coil, TYPE II

Basic Diagnostic Testing

Ignition System Tests Cont'd...

[3] Secondary Ignition Wire Resistance Test (Ω)

This test checks for open circuits or high resistance in the secondary (sparkplug) wires.


Important: Twist and bend the sparkplug wire while measuring the resistance for this test.

- Set the rotary switch to the Resistance (Ω).

Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.
- Connect the test probes to opposite ends of the sparkplug wire.

Typical measurements are approximately 1,000 Ω 's per inch of wire. For example, 10 inch cable = 10,000 Ω .



Basic Diagnostic Testing

Ignition System Tests Cont'd...

[4] Distributor Cap/Rotor Resistance Test (Ω)

This test checks for open circuits or high resistance in the distributor cap and rotor.

- Set the rotary switch to the Resistance (Ω).

Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.


Dist. Cap Center Connector Test: Connect the test probes to opposite ends of the distributor cap terminal (see illustration).

In general, resistance(Ω) should be 5K-10K. Refer to the Manufacturer's specifications.

Rotor Test:

Connect the test probes to opposite ends of the rotor contacts (see illustration).

In general, resistance should be 0.1 Ω or less. Refer to the Manufacturer's specifications.



Basic Diagnostic Testing

Ignition System Tests Cont'd...

[5] Pick-up Coil Resistance (Ω)/Voltage Test (V)

- The **Resistance** test checks for open circuits or high resistance.
- The **Voltage** test compares voltage output to resistance.

Test Procedure

- Set the rotary switch to the **Resistance (Ω)**.

Insert:

- Black lead in **COM** terminal.
- Red lead in **V/ Ω /RPM** terminal.
- Connect the test probes to the pick-up coil leads (see illus.).


Resistance Specifications

The majority of the pick-up coils will test between 500-1500 Ω 's resistance. See manufacturer's specification for required range.

- Set rotary switch to **Volts**. Press the Alternate Function button to select **AC**.

- Crank engine 10-15 seconds at normal speed; measure voltage.

Resistance Test/Voltage Output
Resistance (Ω) on a "good" pick-up coil will match AC output voltage (Ex., 950 Ω 's = 950mV output). Resistance can be good but voltage low if the magnet has lost magnetism or if the reluctor is too far from the stator (Air gap).



Basic Diagnostic Testing

Ignition System Tests Cont'd...

[6] Hall Effect Sensor Voltage Test (V)

This test checks for switching action in any Hall Effect sensor (Ignition, RPM, Crankshaft, etc.)

- Set the rotary switch to the **Voltage (V)** position.

Insert:


- Black Lead in **COM** terminal.
- Red Lead in **V/ Ω /RPM** terminal.
- Connect the Black (-) test probe to the negative (-) post on the battery.

- Turn the ignition key ON. Touch the Red (+) test probe to the three test point shown.

- Ground reading should be the same voltage as the ground (Computer or battery).

- Supply line reading should be the same voltage as the input source (Computer or battery).


- Signal Line reading should be 0 or the same voltage as the input source (Computer or battery). The reading will toggle high and low as the shutter rotates.



Basic Component Testing

This chapter describes a computer controlled sensor and actuator system typically found on today's automobile.

Test procedures are also provided for the basic groups of electrical input and output components commonly found in a computer controlled automotive system. The test procedures are, due to the complexity of components, general theory tests. Be sure to consult the vehicle service manual for component schematics and test specifications.




Basic Component Testing

Computer Controlled Systems

A need for better fuel economy and lower emissions resulted in today's automobiles utilizing computer controlled functions that were previously activated by mechanical, electrical and vacuum devices.

Computerized vehicle control systems are made up of three basic component groups. These groups are:

1. **Sensors:** they are input devices that supply information about engine operating conditions and the surrounding environment to the vehicle computer.
2. **Engine Control Module:** a vehicle computer that processes the information supplied by the sensors, then sends an electronic command to the appropriate component actuators.
3. **Actuators:** these are output devices that may be electrical, mechanical or vacuum components controlled by the vehicle computer.



Basic Component Testing

Computer Controlled Systems Cont'd...

Basic Daignostics for the Computer Controlled Engine

There are two important steps that must always be followed when diagnosing and repairing vehicles with computer controls.

- Do basic engine diagnostics first. Many problems can be traced to lack of routine maintenance on components such as plug wires, filters and spark plugs. Also check for vacuum leaks on any vehicle, new or old. A complete engine diagnosis should precede any electrical system diagnostics.
- Follow the published Diagnostic Charts EXACTLY through every step to make a repair on a computer component.


Basic Component Testing

Computer Controlled Systems Cont'd...

Self-Daignostic Computer Systems

One of the functions of the vehicle computer is to record fault codes produced when a sensor or actuator fails. These failures are usually displayed as a "Current Code" or as an "History Code". Current Codes are further grouped into "Hard Failures" and "Intermittent Failures". Be aware, however, that some vehicle manufacturers use different terminology and older vehicles do not have all of the groups of codes described.

Current Codes are faults that are active.



- Hard Failure causes the dash "Check Engine" light to remain ON.

- Intermittent Failure causes the dash "Check Engine" light to flicker and then go OFF after a short period of time. Generally the trouble code stays in the computer memory.

History Codes are stored codes for faults that have occurred in the past.

Failure Codes

When a failure is detected by the computer, it stores the information in the form of "Fault Codes" (also known as Trouble Codes or Service Codes). These Fault Codes are usually a two or three digit number that identifies the electrical circuit effected. Once these codes have been read the vehicle repair can be started. Be sure to closely follow the vehicle service manual diagnostic precedures, repairs and specifications.

#	DESCRIPTION
13.....	02 SENSOR CIRCUIT
14.....	COOLANT TEMP HI
15.....	COOLANT SENS LO TMP
21.....	TPS VOLTAGE HI
22.....	TPS VOLTAGE LOW
23.....	MANIFOLD AIR TEMP HI
24.....	VSS LOW
25.....	MANIFOLD AIR TEMP LO
32.....	EGR VACUUM ERROR
33.....	MAP ERROR
34.....	MAP SENSOR HIGH
41.....	CYLINDER SELECT ERROR
42.....	EST GROUNDED
44.....	OS SENSOR LEAN
45.....	02 SENSOR RIGH
51.....	PROM ERROR

Note: Typical codes are shown as examples only.

Basic Component Testing

Computer Controlled Systems Cont'd...

Component Testing

Component testing with a meter generally requires detailed schematics and specifications that are provided by the manufacturer. The following section provides general information for the main groups of sensors (input) devices and actuators (output) devices.

The primary input devices (sensors) are:

- Temperature sensors
- 2-wire devices
- 3-wire devices
- Oxygen sensor
- Pressure sensors

Primary output devices (actuators) are a form of an electromagnet that is either ON or OFF. The ON/OFF signal, in general, will be in one of three configurations:


- ON or OFF only (switch)
- Duty cycle measured in percent of high or low time or dwell degrees (mixture control solenoid)

Basic Component Testing

Computer Controlled Systems Cont'd...


Duty Cycle, What is it?

Duty Cycle is the percentage (%) of time a voltage is positive compared to negative: ON compared to OFF. For example; duty cycle measurements are used for Mixture Control solenoids. The amount of ON time is measured as a percent of the total ON/OFF cycle. The meter can read the negative (-) or positive (+) slope and display it as a percent (%) of the total cycle.




Frequency (Hz), What is it?

Frequency is the number of times a voltage pattern repeats positive compared to negative: ON compared to OFF, during one (1) second of time. For example; frequency (Hz) measurements are specified for digitally controlled Manifold Absolute Pressure sensors. The frequency of the ON/OFF signals per second are measured and displayed.



Frequency (Hz) is shown as **Analog**: A continuous positive to negative cycle; or **Digital**: A positive to negative/ON to OFF cycle.



Basic Component Testing

Component Tests (Input)

[1] Temperature Tests


Many components that regulate temperature can be tested by measuring the surface temperature of the area surrounding the component.

- Connect the temperature probe to the meter.
- Set the rotary switch to the Temperature range you desired to be measured.
- Touch the end of the temperature probe directly to the surface of the component to be tested.

Compare your readings with the manufacturers specifications. The temperature should be within $\pm 10^{\circ}\text{F}$ ($\pm 5^{\circ}\text{C}$) of the data stream values.

Some of the components that can be tested for temperature variation are:

- Radiators
- Transmission
- Heaters
- A/C Condensers
- A/C Evaporators
- Engine Coolant Sensors
- Coolant Temperature Switches
- Air Temperature Sensors



Basic Component Testing


Component Tests (Input) Cont'd...

[2] Thermistor (Variable Resistance, 2-wire) Tests

Thermistors are variable resistors that are sensitive to temperature level changes. As the temperature changes, the thermistor's resistance value changes.

- Select the Ohms (Ω) range with the rotary switch.
- Connect the test probes to the sensor terminals.

The Ohms reading should match the temperature of the sensor (see manufacturer's specifications).



Typical thermistor applications are:

- Engine Coolant Temp. (ECT)
- Air Charge Temp. (ACT)
- Manifold Air Temp. (MAT)
- Vane Air Temp. (VAT)
- Throttle Body Temp.(TBT)

Basic Component Testing

Component Tests (Input) Cont'd...

Thermistor (Variable Resistance, 2-wire) Tests Con't...


Voltage Presence

- Disconnect the vehicle wiring harness at the sensor.
- Select the Voltage range with the rotary switch.

Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.
- Connect the test probes in parallel: Positive (+) to the circuit coming from the power source, negative (-) to the negative circuit from the sensor.
- Turn the ignition switch ON; do not start the engine.

Measurement should be 5 - 9 volts (check the manufacturer's specifications).



Basic Component Testing

Component Tests (Input) Cont'd...

Thermistor (Variable Resistance, 2-wire) Tests Con't...


Voltage Change

Connect jumper wires between the connector and the sensor.

- Connect the test probes in parallel: Positive (+) to the circuit coming from the power source, negative (-) to the negative circuit from the sensor.
- Start the engine.

The voltage should change as the temperature changes. This is the signal that is sent to the computer for processing.

Refer to the manufacturer's specifications. If the voltage change is not within specifications, look for sources of resistance due to poor connectors, connections or breaks in the wiring.



Basic Component Testing

Component Tests (Input) Cont'd...

[3] Potentiometers (Variable Resistance, 3-wire) Tests

The potentiometer is a variable resistor. The signal it generates is used by the vehicle computer to determine position and direction of movement of a device within the component.


Resistance

- Select the Ohms (Ω) range with the rotary switch.
- Disconnect the sensor.
- Connect the test probes to the Signal Line and to the Ground (refer to manufacturer's schematic).

Watch the bar graph display; the Ohms reading should change as the signal arm on the potentiometer is moved (signal sweep).

Typical potentiometer applications are:

- Throttle position Sensor (TPS)
- Exhaust Gas Recirculation valve position sensor (EVP)
- Vane Air Flow Meter (VAF)



Basic Component Testing

Component Tests (Input) Cont'd...

Potentiometers (Variable Resistance, 3-wire) Tests


Reference Voltage Test

- Disconnect the vehicle wiring harness at the sensor.
- Select the Voltage range with the rotary switch.

Insert:

- Black lead in COM terminal.
- Red lead in V/ Ω /RPM terminal.
- Connect the test probes in parallel: Positive (+) to the computer reference voltage circuit, negative (-) to the negative system ground circuit from the sensor.
- Turn the ignition switch ON; do not start the engine.

Watch the bar graph display. Reading should be 5 - 9 volts (check the manufacturer's specifications).



Basic Component Testing

Component Tests (Input) Cont'd...


Potentiometers (Variable Resistance, 3-wire) Tests

Voltage Change

- Connect jumper wires between the connector and the sensor.
- Connect the test probes in parallel: Positive (+) to the signal line, negative (-) to the ground circuit.
- Turn the ignition key ON, do not start the engine.

Observe the bar graph display. The voltage drop should change as the position of the signal arm on the potentiometer moves (signal sweep).

Refer to the manufacturer's specifications. If the voltage change is not within specifications, look for sources of resistance due to poor connectors, connections or breaks in the wiring.



Basic Component Testing

Component Tests (Input) Cont'd...

[4] Oxygen Sensor (O₂) Test

The Oxygen Sensor samples the amount of Oxygen in the exhaust stream. The voltage produced by the O₂ sensor is a direct ratio to the oxygen level in the exhaust stream. This voltage is used by the computer to change the air/fuel mixture.


The test will check oxygen sensor signal output levels.

- Disconnect the vehicle wiring harness at the sensor. Install a jumper wire.
- Select the Voltage range with the rotary switch.

Insert:

- Black lead in COM terminal.
- Red lead in V/Ω/RPM terminal.
- Connect the test probes in parallel: Positive (+) to the jumper wire, negative (-) to the engine ground.
- Vehicle engine must be running at operating temperature (fast idle at 2,000 RPM for two minutes).

Voltage readings should move between 0.2 (lean) and 0.8 (rich). The average DC voltage should be around 0.50.



Basic Component Testing

Component Tests (Input) Cont'd...

[5] Pressure sensor Tests

The electrical tests for pressure sensors such as the Manifold Absolute Pressure (MAP) and Barometric Pressure (BARO) vary greatly, depending upon type and manufacturer. Consult the vehicle service manual for the schematic, specifications and test procedures.

General Testing Procedures

Note: You cannot do a resistance (Ω) test for pressure sensors.

Analog Sensor

An analog sensor can be tested with the same series of voltage(V) tests suggested for 3-wire potentiometers. In place of "sweeping" the sensor, use a vacuum pump to vary the pressure on the sensor.

Digital Sensor

Set the meter rotary switch to the Hz setting and perform the same series of tests suggested for 3-wire potentiometer voltage tests. In place of "sweeping" the sensor, a vacuum pump is generally used to vary the pressure on the sensor. In all cases, refer to a vehicle service manual for the correct procedure.

Basic Component Testing

Component Tests (Output)

Output Devices

The electrical tests for output devices vary greatly, depending upon type and manufacturer. Consult the vehicle service manual for the schematic, specifications and test procedures.

Primary output devices (actuators) are a form of an electromagnet that is either ON or OFF. The ON/OFF signal, in general, will be in one of three configurations:


- **ON or OFF only (switch)** Check for continuity with the switch in the ON and OFF position.



Switch

- **Duty Cycle (Mixture Control Solenoid)**

Measure the percent of high (+) or low (-) time in a duty cycle. In most cases the low (-) time is the ON time.




Mixture Control Solenoid

Specifications

General Specifications

GENERAL SPECIFICATIONS

- **Display:** 3½ digit (3200 counts) liquid crystal display (LCD), with function and units sign annunciators.
- **Analog Bar Graph:** 34 segments with measurements 12 times per second.
- **Polarity:** Automatic, (—) negative polarity indication.
- **Overrange Indication:** "OL" mark indication.
- **Low Battery Indication:** The  is displayed when the battery voltage drops below the operating level.
- **Measurement Rate:** 2 times per second, nominal.
- **Operating Environment:** 0°C to 50°C (32°F to 122°F) at < 70% R.H.
- **Storage Environment:** -20°C to 60°C (-4°F to 140°F) at < 80% R.H.
- **Temperature Coefficient:** 0.2 x (specified accuracy) / °C (<18°C or >28°C).
- **Power:** Single standard 9 Volt battery (NEDA 1604 or IEC 6F22).
- **Battery Life:** 200 hours typical with alkaline battery.
- **Fuse:** 10A/600V, 6.3x25mm fast acting ceramic type. 0.5A/250V, 5x20mm fast acting ceramic type.
- **Dimensions:** 147mm (H) x 70mm (W) x 39mm (D).
- **Weight:** Approx. 222g (Meter Only), 355g (With Holster).

Specifications

Electrical Specifications

ELECTRICAL SPECIFICATIONS

*Accuracy is given as \pm ([% of reading]+[number of least significant digits]) at 18°C to 28°C (65°F to 83°F), with relative humidity up to 70%.

RPM (Tach)

Ranges: 600-3200, 3200-12000 (x10 RPM)

Resolution: 1 RPM

Effect Reading: >600 RPM

Accuracy: \pm (2% rdg + 4dgts)

Overload protection: 500 VDC or RMS AC

% DUTY CYCLE

Range: 1.0% - 90.0%

Resolution: 0.1%

Pulse width: >100 μ s, <100ms

Accuracy: \pm (2.0% rdg + 5 dgts)

Overload protection: 500 VDC or RMS AC

DWELL ANGLE

No. of cylinders: 4, 5, 6, 8

Ranges: 0 - 90.0° (4 CYL), 0 - 72.0° (5 CYL), 0 - 60.0° (6 CYL),

0 - 45.0° (8 CYL)

Resolution: 0.1°

Accuracy: \pm (2.0% rdg + 5 dgts)

Overload protection: 500 VDC or RMS AC

TEMPERATURE

Ranges: -20 to 750°C, -4 to 1400°F

Resolution: 1°C/1°F

Accuracy: \pm (3.0% rdg + 2°C)

\pm (3.0% rdg + 4°F)

Sensor: Type K Thermocouple

Input protection: 60VDC or 24VAC rms

